



## How to synchronise two barriers

In order to synchronise the operation of two SOSEC/INSTABOOM barriers, it is necessary to connect four cables between the control boards. This process ensures that any Open, Close or Safety switch on either device will give the same instruction to the other.

Using an appropriate cable with at least 4 cores, connect the two devices together as shown in the diagram below.

