

Pairing a Mitto fob with your SOSEC barrier

Open up the enclosure containing the control board. You should see the circuit board similar to this:



On the raised section, push and release the small red button closest to the cable connections, highlighted in this picture. The LED to the left of it will start to flash.



Take your new fob. Depress and hold both buttons down until a steady light is shown on the control board and the fob. Release both buttons and then push and release the button to which you want to pair the barrier.

The fob should now operate the barrier.