

Quick Start Guide for PAIRED units



Turn on all units (2, 3 or 4) and check voltage on. Below 11.8V will require unit(s) to be charged*

All units will run through the set up process and move 3 times.

Only proceed from this point with units that are known to be fully paired and fully charged.

If 'Site Prep Mode' is enabled, they will finish with the sign facing away from/oblique to traffic.



Deploy Traffic Management set up, according to required standards. Set Stop/Go poles in place and sand bag the handle.



When ready to 'Go Live', press and hold remote BUTTON 1 for 2 seconds, until master beacon stops flashing. Units communicate and go live by turning to STOP.



Operate units in line of sight of full set up at all times. Press any button to bring all to STOP. The designated button will bring allocated sign to GO position.

- CHARGING**
1. Generally charge signs weekly.
 2. Any voltage below 11.8V will affect correct operation.
 3. If units below 10V, charge for max 20 mins and disconnect.
 4. Check voltage over 10V and reconnect charger.
 5. Do not charge more than 6 hours.
 6. Charge with lid open.

For access to full video tutorials and user guides, please visit

www.solargates.co.uk/resources