

## Quick Start Guide for PAIRED units



Turn on all units (2, 3 or 4) and check voltage display is 'on'. If below 11.8V, unit(s) must be charged.\*

All units will run through the set up process and move 3 times.

Only proceed from this point with units that are both fully paired and fully charged.

If 'Site Prep Mode' is enabled, they will finish with the sign facing away from/oblique to traffic.



Deploy Traffic Management set up, according to required standards. Set Stop/Go poles in place and sandbag handle if conditions require.




When ready to 'Go Live', press and hold remote BUTTON 1 for two seconds (until master beacon stops flashing). Units communicate and go live by turning to STOP.



Operate units in line of sight of entire set up at all times. Press any button to bring all to STOP. The designated button will bring allocated sign to GO position.

### CHARGING

1. Generally charge weekly.
2. Below 11.5V will affect operation.
3. ENSURE CHARGER IS ON NORMAL MODE.
4. Do not charge for more than six hours.
5. Always charge with lid open.



\*For access to full video tutorials and user guides, please visit

[www.solargates.co.uk/resources](http://www.solargates.co.uk/resources)